

Virtual Jeff^(R) PRO

DEEP DIVE



WHAMMY INSTALL

WHAMMY INSTALL

Installation is simple and needs no tools or mods to your guitar. The Deep Dive - WHAMMY POSITION has tips on fitting VJ to various style guitars.

10 SECONDS

Mounting the whammy is straightforward:

1. Choose the best location
2. Clean the guitar surface of polish or grime
3. Remove the backing from the adhesive tapes on the mount
4. Position the mount and press down firmly for 10 seconds

The whammy is ready to use immediately, but wait 1-2 hours before you try to slide it off the mount. This will let the special adhesive stabilize fully.

IMPORTANT: Don't forget to leave a small gap between the whammy and bridge/stud tailpiece so you can change strings!

TIP: Before attaching it to your guitar, slide the whammy on and off the mount a few times. This will make it easier to remove once it's mounted. (The whammy slides off the mount in the opposite direction to the arrows). There's also a handy tip in the Deep Dive - WHAMMY POSITION article/video on making removal easier.

VIDEO

Make sure you watch the Deep Dive INSTALL video to see how it's done... it's easier to follow than any text description!

Note: The Deep Dive - WHAMMY POSITION has important information on the mount, the special adhesive, test fitting and more.